



OVL Linear Controller - Quick Menu Guide

The Linear Over-Voltage Limiter has a built in control panel that allows the user to display the controller's status, test functions and change various setpoints on site. The **MENU** key is used to navigate from one menu to the next, the **Up** and **Down** keys to navigate through each menu, and the **SELECT** switch is used where shown. Refer to the OVL manual for the full list of available functions.



1] General Information.

- Menu 0 : Output status and any alarms.
- Menu 1 : High Current Alarm 1 Settings.
- Menu 2 : High Current Alarm 2 Settings.
- Menu 3 : High Voltage Alarm Settings.
- Menu 4 : Load Cut (Output) Settings, Relay Function, Display Mode.



To return to Menu 0 at any time, press **MENU** and **UP** or **MENU** and **DOWN** simultaneously.